



Clipp-Aid® - Product Information



What is Clipp-Aid®?

Clipp-Aid® is a brand new technology that brings dull blades back to life.

Each Clipp-Aid® sachet contains specially formulated crystals made of natural ingredients that provide a quick, simple and easy-to-use method for stylists to sharpen their own metal clipper & trimmer blades in the salon.

How is Clipp-Aid® used?



Clipp-Aid® will sharpen blades by running the clipper or trimmer with the teeth of the blade in the crystals, and moving the clipper back and forth through the crystals for around 1 to 2 minutes. It's just 4 simple steps:

1 SET UP



2 SHARPEN



3 CLEAN



4 OIL



How frequently should Clipp-Aid® be used?

For normal use, we recommend using Clipp-Aid® every 2 to 4 weeks, depending on the dullness of the blade. New blades require less frequent use. The frequency of use will depend on how often the clippers and trimmers are used and how well the blades are maintained (ie. cleaned and oiled).

Note: Clipp-Aid® may not replace the need for a professional blade sharpener, but it can be used to extend the life of blades between sharpenings and provide a quick solution for stylists whose blades are getting dull.

How do I know when the crystals are fully used?

During use, the crystals are ground down to a fine powder that is a lighter colour. Once all the crystals are a lighter colour they have been fully used. Running the clipper through the lighter-coloured powder will not improve the blades any further.



Can Clipp-Aid® be re-used?

No. Once the crystals in the sachet turn into a lighter-coloured powder, the sachet should be discarded .

How do I know when to use Clipp-Aid®?

When clipper blades become dull they do not cut cleanly and will snag the clients' hair, slowing down the stylist. This is when Clipp-Aid® should be used. Clipp-Aid® reduces the time it takes to do a haircut, saving the stylist time and money.



Clipp-Aid® - Product Information



Can I use Clipp-Aid® on my old blades?



When first using Clipp-Aid®, the age of the blade does make a difference. However, as long as the blade is not damaged, Clipp-Aid® can be used to bring it back to life. Blades that are in very poor condition, or are very dull, may need 2 or 3 Clipp-Aid® sachets in a row the first time it is used. But once sharpened, you can transition to using Clipp-Aid® every 2 to 4 weeks to keep the blades sharp.

Can Clipp-Aid® damage my clippers?

Research shows no risks or damage to clippers or trimmers with the proper use of Clipp-Aid® products.

WARNING: Trimmer blades have finer teeth and are more sensitive than clipper blades. It is important to only use the specially formulated **Trimmer Clipp-Aid®** (blue sachet) for trimmer blades. Also, ensure any dirt, dust, grime and other debris is removed from between the blades after using Clipp-Aid®. We recommend using a blade wash (such as "CLEAN BLADES" Lubricant & Sanitiser) or removing the blade from the machine to clean.

Which Clipp-Aid® is best for me?

There are 3 different sachets of Clipp-Aid® available containing a carefully measured quantity of crystals to suit different blade sizes. There is also a sachet designed specially for trimmer blades.



Blade Type	Box Colour	Hair Stylist Blade Size	Animal Grooming Blade Size
Trimmer Blade	Blue	Trimmers, 00000	Trimmers, 00000
Standard Clipper Blade	Red	0000, 000, 0A	50, 40, 30, 15, 10
Medium Clipper Blade	Orange	1A, 1, 1.5	9, T-84, 8.5, 7
Large Clipper Blade	Yellow	2, 3.5 & 3.75	5, 4, 3.75, 0.625, 0.75

E.G. The Andis US-Pro, Wahl Super Taper or Wahl Taper 2000 clipper will require the STANDARD size (i.e. Red) Clipp-Aid® sachet.